



Spare parts list telescopic pole ERS233S




image number	product code	name of the item	quantity
1	ERS060	hexagon nut left-hand thread	1
2	ERS090	lock nut 4 mm	1
3	ERS070	pin for holding clamp	1
4	ERS080	screw M4 Allen	1
5	ERS040	lock lever	1
6	ERS050	screw left-hand thread	1
7	ERS010	holding clamp 23/30	1
9	ERS23/30	lock clamp 23/30 completely	1
8	ERS020	holding clamp 30/37	1
10	ERS30/37	lock clamp 30/37 completely	1
11	ERS130	guide 23 x 15	3
12	ERS140	guide 30 x 15	3
13	ERS110	endcap 233/490	1
14	ERS233.1	1st tube 233 without small parts	1
15	ERS233.2	2nd tube 233 without small parts	1
16	ERS233.3	handhold 233 without small parts	1



spare parts list telescopic pole ERS340S




image number	product code	name of the item	quantity
1	ERS060	hexagon nut left-hand thread	1
2	ERS090	lock nut 4 mm	1
3	ERS070	pin for holding clamp	1
4	ERS080	screw M4 Allen	1
5	ERS040	lock lever	1
6	ERS050	screw left-hand thread	1
7	ERS010	holding clamp 23/30	1
8	ERS23/30	lock clamp 23/30 completely	1
9	ERS130	guide 23 x 15	3
10	ERS100	endcap 340	1
11	ERS340.1	1st tube 340 without small parts	1
12	ERS340.2	handhold tube 340 without small parts	1



spare parts list telescopic pole ERS490S




image number	product code	name of the item	quantity
1	ERS060	hexagon nut left-hand thread	1
2	ERS090	lock nut 4 mm	1
3	ERS070	pin for holding clamp	1
4	ERS080	screw M4 Allen	1
5	ERS040	lock lever	1
6	ERS050	screw left-hand thread	1
7	ERS010	holding clamp 23/30	1
9	ERS23/30	lock clamp 23/30 completely	1
8	ERS020	holding clamp 30/37	1
10	ERS30/37	lock clamp 30/37 completely	1
11	ERS130	guide 23 x 15	3
12	ERS140	guide 30 x 15	3
13	ERS110	endcap 233/490	1
14	ERS490.1	1st tube 490 without small parts	1
15	ERS490.2	2nd tube 490 without small parts	1
16	ERS490.3	handhold tube 490 without small parts	1



spare parts list telescopic pole ERS630S




image number	product code	name of the item	quantity
1	ERS060	hexagon nut left-hand thread	1
2	ERS090	lock nut 4 mm	1
3	ERS070	pin for holding clamp	1
4	ERS080	screw M4 Allen	1
5	ERS040	lock lever	1
6	ERS050	screw left-hand thread	1
7	ERS010	holding clamp 23/30	1
10	ERS23/30	lock clamp 23/30 completely	1
8	ERS020	holding clamp 30/37	1
11	ERS30/37	lock clamp 30/37 completely	1
9	ERS030	holding clamp 37/44	1
12	ERS37/44	lock clamp 37/44 completely	1
13	ERS130	guide 23 x 15	3
14	ERS140	guide 30 x 15	3
15	ERS150	guide 37 x 15	3
16	ERS120	endcap 630	1
17	ERS630.1	1st tube 630 without small parts	1
18	ERS630.2	2nd tube 630 without small parts	1
19	ERS630.3	3rd tube 630 without small parts	1
20	ERS630.4	handhold tube 630 without small parts	1

spare parts list telescopic pole ERS8000S




image number	product code	name of the item	quantity
1	ERS060	hexagon nut left-hand thread	1
2	ERS090	lock nut 4 mm	1
3	ERS070	pin for holding clamp	1
4	ERS080	screw M4 Allen	1
5	ERS040	lock lever	1
6	ERS050	screw left-hand thread	1
7	ERS010	holding clamp 23/30	1
10	ERS23/30	lock clamp 23/30 completely	1
8	ERS020	holding clamp 30/37	1
11	ERS30/37	lock clamp 30/37 completely	1
9	ERS030	holding clamp 37/44	1
12	ERS37/44	lock clamp 37/44 completely	1
14	ERS44/51	lock clamp 44/51 completely	1
13	ERS035	holding clamp 44/51	1
15	ERS130	guide 23 x 15	3
16	ERS140	guide 30 x 15	3
17	ERS150	guide 37 x 15	3
18	ERS160	guide 44 x 15	3
19	ERS125	endcap 8000	1
20	ERS8000.1	1st tube 8000 without small parts	1
21	ERS8000.2	2nd tube 8000 without small parts	1
22	ERS8000.3	3rd tube 8000 without small parts	1
23	ERS8000.4	4th tube 8000 without small parts	1
24	ERS8000.5	handhold tube 8000 without small parts	1